ALLEN&HEATH



WARNING — HIGH VOLTAGES

Power Supply Unit (PSU) work should only be carried out by qualified personnel.

We recommend that you use an approved Allen & Heath service centre for all power supply work.

Please contact your local Allen & Heath distributor for more details.

http://www.allen-heath.com/

GL²²⁰⁰

Audio mixing console



SERVICE MANUAL

PUBLICATION: AP3389

CONTENTS

Introduction	3
Service and Technical Support	3
Safety Warning & General Precautions	
The <i>GL2200</i> Range & Options	4
Flightcasing the Console	4
Dimensions	4
Specifications & Connections	5
Ordering a <i>GL2200</i> Console, Options and Documentation	6
Ordering an Assembly	7
Ordering a Spares Kit	8 - 9
Front Panel Layout	10
Rear Panel Layout	11
Block Diagram	12
GL2200 INPUT Circuit Board component Ident	AG3395
GL2200 INPUT Circuit Diagram	C3395
GL2200 STEREO Circuit Board component Ident	AG3428
GL2200 STEREO Circuit Diagram (Page 1 of 2)	C3428
GL2200 STEREO Circuit Diagram (Page 2 of 2)	C3428
GL2200 GROUP Circuit Board component Ident	AG3425
GL2200 GROUP Circuit Diagram (Page 1 of 2)	C3425
GL2200 GROUP Circuit Diagram (Page 2 of 2)	C3425
GL2200 LEFT Circuit Board component Ident	AG3426
GL2200 LEFT Circuit Diagram (Page 1 of 3)	C3426
GL2200 LEFT Circuit Diagram (Page 2 of 3)	C3426
GL2200 LEFT Circuit Diagram (Page 3 of 3)	C3426
GL2200 RIGHT Circuit Board component Ident	AG3427
GL2200 RIGHT Circuit Diagram (Page 1 of 2)	C3427
GL2200 RIGHT Circuit Diagram (Page 2 of 2)	C3427
GL2200 OSC/NOISE Circuit Board component Ident	AG3519
GL2200 OSC/NOISE Circuit Diagram	C3519
GL2200 PSU Circuit Board component Ident	AG3504
GL2200 PSU Circuit Diagram	C3504

Warning to the Service Engineer

Allen & Heath warns that any unauthorised changes or modifications to the *GL2200* unit may invalidate the legal compliance of the unit and could void the user's authority to operate the equipment.

GL2200 Service Manual AP3389 Issue 1. Copyright © 1999 Allen & Heath. All rights reserved

Manie	ACTURED	IN FNGI	AND BY.
IVIAIVUT	ACTURED	11A FIA(3F	AIND DI.

ALLEN & HEATH
Kernick Industrial Estate
Penryn, Cornwall, TR10 9LU. UK

http://www.allen-heath.com

H A DIVISION OF HARMAN INTERNATIONAL INDUSTRIES Ltd

_		_			_	
AΠ	FN	X.	HEA	TH	$\mathbf{A}\mathbf{G}$	FNT

Introduction

The information presented in this manual is intended for competent technical personnel to carry out service and product support for the *GL2200* range of consoles. We assume that the reader is familiar with the related electronic theory and audio terminology, and is able to carry out servicing, faultfinding and repair of audio equipment of this type. Service personnel should also be familiar with audio systems, mains earthing and power requirements, as well as handling precautions.

For information on the configuration, operation and application of the *GL2200* range, please refer to *GL2200* User Guide (A&H Part no: AP3388).

Whilst we believe the information in this manual to be reliable we do not assume responsibility for inaccuracies. We also reserve the right to make changes in the interest of further product development.

Service and Technical Support

Under normal conditions the *GL2200* does not require user maintenance or internal calibration. Any service work required should be carried out by qualified service personnel only.

We are able to offer further product support through our world-wide network of approved dealers and service agents. You can also access our Web site on the Internet for information on our product range, assistance with your technical queries or simply to chat about audio matters. To help us provide the most efficient service please keep a record of the console serial number, the date and place of purchase to be quoted in any communication regarding this product.

SAFETY WARNING!



Mains electricity is dangerous and can kill. Mains voltage is present within the console power supply unit.

Do not remove the power supply cover with mains electricity connected. To ensure your safety, mains earth is connected to the chassis through the power lead. Do not remove this mains earth connection.



To avoid the risk of fire, replace the mains fuse only with the correct value and type as indicated on the power supply unit.



The internal power supply unit contains no serviceable components and must be replaced as a complete unit if a failure occurs.

General Precautions

Your *GL2200* is ruggedly constructed to give many years of reliable operation. However, you will extend the life of the console and preserve its cosmetics by applying these simple common sense precautions.

- Avoid storing or using the mixing console in conditions of excessive heat or cold, or in positions where it is likely to be subject to vibration, dust, dirt or moisture.
- Do not use any liquids to clean the control surface of the console, a soft dry brush or dry lint-free cloth is ideal.
- Use only water or ethyl alcohol to clean the trim and scribble strips. Other solvents may cause damage to paint or plastic parts.
- The faders, switches and potentiometers are lubricated for life. The use of electrical lubricants on these parts is not recommended.
- Avoid using the console close to strong sources of electromagnetic radiation (e.g. video monitors, high power electric cabling): this may cause degradation of the audio quality due to induced voltages in connecting leads and chassis. For the same reason, always site any external power supply away from the unit.

The GL2200 Range

12, 16, 24 and 32 channel models

GL2200-412	10 mono, 2 stereo, 4 groups, 6 aux, 2 stereo returns, L, R, Mono sum
GL2200-416	14 mono, 2 stereo, 4 groups, 6 aux, 2 stereo returns, L, R, Mono sum
GL2200-424	22 mono, 2 stereo, 4 groups, 6 aux, 2 stereo returns, L, R, Mono sum
GL2200-432	30 mono, 2 stereo, 4 groups, 6 aux, 2 stereo returns, L, R, Mono sum


Options

GL2200-SL1 Sys-link buss expander, one kit per console RPS9 2U rack mount power supply for backup

Flightcasing The Console

If the console is to be regularly moved we recommend that it is installed in a foam-lined flightcase. At all times avoid applying excessive force to any knobs, switches or connectors.

Dimensions for flightcasing the console are shown below:




```
      GL2200 - 412
      width 548mm

      GL2200 - 416
      width 668mm

      GL2200 - 424
      width 920mm

      GL2200 - 432
      width 1160mm
```



Dimensions

Unpacked			Packed	Packed				
	Width	depth	height	weight(kg)	Width	depth	height	weight(kg)
GL2200-412	548	572	155	16	700	750	280	20
GL2200-416	668	572	155	18	815	750	280	23
GL2200-424	920	572	155	24	1065	750	280	29
GL2200-432	1160	572	155	30	1325	750	280	35
RPS9 power supply	483	140	96	6	540	270	180	8

Specifications

0 dBu = 0.775 Volts rms 0 dBV = 1 Volt rms

HEADROOM: +21dB
MAX OUTPUT:XLR +25dBu 2kohm max loadJACK +21dBu 2kohm max load
METERS: L, Rpeak reading 12 bar LED Groups 1-4peak reading 4 segment LED Channels.peak reading 4 segment LED
PEAK LEDs: Turn on 5dB before clipping
FREQUENCY RESPONSE referred to 1kHz @ +4dBu: Any input to any output
DISTORTION: THD+Noise @ +14dBu 1kHz Mic in to L-R output, 40dB gain
CMRR Mic in, 40dB gain @ 1kHz>88dB

CROSSTALK: Referred to driven channel @ 1kHz Adjacent channel
NOISE: Measured rms, 22kHz bandwidth Mic input EIN (150 ohm source)
POWER SUPPLY:

Connections

INPUTS:			
Mic in	XLR	pin 2 hot, 3 cold, balanced	>2k Ohmvariable -60 to -20dBu
Line in	XLR	pin 2 hot, 3 cold, balanced	>10k Ohmvariable -30 to +10dBu
	or TRS jack	tip hot, ring cold, balanced	>10k Ohmvariable -30 to +10dBu
Stereo Ch Line in	TRS jack	tip hot, unbalanced	>8k Ohm20dBu min
Stereo Return	TRS jack	tip hot, unbalanced	>6k Ohm10dBV min
2-Track Return	RCA PHONO	unbalanced	>10k Ohm10dBV min
Insert Return	TRS jack	tip send, ring return, unbalanced	>6k Ohm0dBu (chan), -2dBu (out)

OUTPUTS:			
L-R, Group out	XLR	pin 2 hot, 3 cold, balanced	<75 Ohm+4dBu, +27dBu max
Direct out	TRS jack	tip hot, impedance balanced	.<75 Ohm0dBu
2-Track sends	RCA PHONO	unbalanced	.<75 Ohmvariable +21dBu max
Aux out	TRS jack	tip hot, impedance balanced	<75 Ohmvariable +21dBu max
Mono out	XLR	tip hot, ring cold, balanced	<75 Ohm+4dBu, +27dBu max
Insert send	TRS jack	tip send, ring return, unbalanced	<75 Ohm0dBu (chan), -2dBu (out)
Monitor out	TRS jack	tip left, ring right, unbalanced	<75 Ohmvariable +21dBu max
Phones out	TRS jack	tip left, ring right	.for stereo headphones 30 to 600 Ohms

Ordering a GL2200 Console

To order a new console please specify the model number and AC mains voltage required.

MODEL	DESCRIPTION	ORDER CODE
GL2200 12 Channel	10 mono + 2 stereo input channels	GL2200-412/volts
GL2200 16 Channel	14 mono + 2 stereo inputs channels	GL2200-416/volts
GL2200 24 Channel	22 mono + 2 stereo inputs channels	GL2200-424/volts
GL2200 32 Channel	30 mono + 2 stereo inputs channels	GL2200-432/volts

Ordering an Option

To order an option please specify the serial number of the console that is to have the option fitted.

MODEL	DESCRIPTION	ORDER CODE
GL2200-SL1	GL2200 SYS-LINK KIT	GL2200-SL1
	GL2200 Balanced Output IC option	AE0302
RPS9	2U external linear power supply	RPS9/volts

Manuals and Support Documentation

DESCRIPTION	ORDER CODE
GL2200 User Guide	AP3388
GL2200 Service Manual	AP3389
GL2200 Brochure	AP3390
GL2200 SYS-LINK Fitting Instructions	AP3622
GL2200 SYS-LINK Application Note	AP3623
RPS9 User Guide	AP0334

Service Tools

The tools required to service the *GL2200* are standard to an electronic service workshop and are easily obtainable. The following items are necessary for disassembly and service access:

 1-point Crosshead screwdriver (M3, 4AB)	AT0004
 2-point Crosshead screwdriver (M4, 6AB)	AT0002
11mm AF Nutdriver (potentiometer nuts)	
12mm AF Nutdriver (jack nuts)	

Ordering an Assembly

The following assemblies are supplied fully tested. Please note that several of these need to be assigned according to their position in the console. This is achieved by soldering wire links or assignment pads. It is best to check the assignment settings of the assembly you are replacing before removing it from the console. Please quote the description and order code for the part required.

Printed Circuit Board (PCB) Assemblies:

* specify position of PCB assembly			
Mono Input & Connector PCB assembly	002-412		
Stereo Input & Connector PCB assembly	002-442		
* Group PCB assembly	002-439		
OSC/Noise PCB assembly	002-453		
Left PCB assembly	002-440		
Right PCB assembly	002-441		
Switch Mode PSU assembly (12 & 16)	002-456		
Switch Mode PSU assembly (24 & 32)	002-457		

IDC connector harnesses:

GL2200-412	20 way Main harness	AL3535
GL2200-416	20 way Main harness	AL3536
GL2200-424	20 way Main harness	AL3537
GL2200-432	20 way Main harness	AL3538

The Chassis Trim


GL2200 (all formats)	Left & Right Chassis side trims	AA2539-L/R
	Write-on strip (specify console size)	AK0327

Ordering a Spares Kit

It is recommended that the spares kit order code **002-481** is held and maintained by the service agent to enable in-field service repairs to the *GL2200* independent of the ALLEN & HEATH factory. Commonly available items such as resistors, capacitors, tools and soldering equipment are not included. The contents of the kit are listed below and are supplied in a cabinet of drawers. Individual spare parts may be ordered. Please quote the description and order code for the part required.

ESCRIPTION	ORDER CODE	QTY
ixings:		
Screw 4AB x 5/16 CSK Pozi Black	AB0059	5
Screw 6AB x 3/8 Pan Pozi Black	AB0062	10
Screw M3 x 6mm Pan Pozi Black	AB0072	5
Screw M3 x 8mm Pan Pozi Black	AB0073	10
Screw M3 x 12mm Pan Pozi Black	AB0078	5
Screw M3 x 16mm Pan Pozi Black	AB0079	5
Nylock Nut M3	AB0102	5
Screw M3 x 4mm Pan Pozi Black	AB0233	10
Screw 4AB x 1/4 Pan Pozi Plated	AB0252	4
Screw 6B x 1/4 Trunc Pozi Zinc	AB2083	10
Screw 4 x 5/16 Pan Pozi Plastite	AB2771	5
Screw 6B x 5/16 Pan Pozi Black	AB2809	5
Screw 4 x 5/16 Poly Pan Pozi	AB2810	10
nobs and caps:		
Knob Red & Grey 11mm D	AJ2074	10
Knob Blue & Grey 11mm D	AJ2075	10
Knob Light Blue & Grey 11mm D	AJ2076	10
Knob Green & Grey 11mm D	AJ2077	10
Knob Dark Grey & Grey 11mm D	AJ2078	10
Knob Yellow & Grey 11mm D	AJ2079	10
Knob Brown & Grey 11mm D	AJ2080	10
Button 5.5mm Square Grey	AJ2864	10
Button 10 x 5mm Rectangular Grey	AJ2865	10
Button Round Black	AJ2887	1
Button 5.5mm Square White	AJ2960	10
Button 5.5mm Square Red	AJ2961	10
Button 10 x 5mm Rectangular White	AJ2962	10
Button 10 x 5mm Rectangular Black	AJ3228	3
Fader Knob 11mm White+Black Line	AJ8078	10
Fader Knob 11mm Red+Black Line	AJ8079	5
Fader Knob 11mm Yellow+Black Line	AJ8080	5
Fader Knob 11mm Blue+Black Line	AJ8081	5

Pot 10K centre click (103AC 14mm wide)	AI8008	5
Pot 5K (502RD 11mm wide)	Al8111	5
Fader 10KA x 2 60mm	AI8051	5
Fader 10KD 100mm	Al8117	10
Fader 10KD x 2 100mm	Al8118	5
Switch 2PCO Latching 90 Deg	AL0162	5
Switch 4PCO Latching	AL0333	5
Switch 2PCO Momentary	AL0374	5
Jack Socket Headphone	AL0328	1
XLR 3 Pin Female Vertical PCB Mount	AL2410	5
XLR 3 Pin Male Vertical PCB Mount	AL2411	5
Molex 0.1" Male 10 Pin 90 Deg	AL2572	3
Molex 0.1" Female 10 way Straight	AL2573	3
Jack Socket ¼" Stereo Unswitched	AL3407	5
Jack Socket ¼" Stereo Switched	AL3410	5
Pot Nut 9mm	AB8050	10
LEDs and Semiconductors:		
Transistor BC549 NPN	AE0020	3
Transistor BC638 PNP	AE0020 AE0037	2
	AE0037 AE0068	2
Transistor BC637 NPN		<u>2</u> 5
Transistor 2N4403 PNP	AE0273	
Transistor BC556B PNP	AE3001	2
Transistor 2SB737 PNP	AE8069	5
IC Op-Amp TL072	AE0046	5
IC LM339N Quad Comparator	AE0071	2
IC CMOS 4053B	AE0117	1
IC Op-Amp NE5532N	AE0221	5
LED 3mm T1 Yellow	AE0084	5
LED 3mm T1 Green	AE0085	5
LED 3mm T1 Red	AE0086	5
LED Bar Rectangular 12 Way	AE2701	1
LED 5 x 2mm Rectangular Red Flat Top	AE3502	10
Power Supply:		
Mains Lead IEC-2pin EURO	AH0205	-
Mains Lead IEC-3pin UK	AH0206	-
Mains Lead IEC-3pin US (C33)	AH0323	-
Mains Fuse 20mm 1A Anti-Surge	AL0305	10
Miscellaneous:		
GL2200-412 Packing Assembly	002-435	-
GL2200-416 Packing Assembly	002-436	-
GL2200-424 Packing Assembly	002-437	-
GL2200-432 Packing Assembly	002-438	-
Flex Cable 12 Way 90mm	AH2228	5



GL2200 REAR PANEL

